



Risk of Fire or Shock:

Supply conductors and connectors must be rated minimum 60°C. If uncertain, consult an electrician.

CAUTION:

To avoid possible electric shock, be sure that power supply is turned off at fuse box or circuit breaker before attempting installation or servicing of the fixture. For safest operation read and become familiar with complete installation instructions prior to use.

This luminaire must be installed in accordance with the NEC or your local electrical code. If you are not familiar with these codes and requirements, consult a qualified electrician.

The MAXCOR™ WPR - LED Residential Wrap is designed for surface mount applications using the included hardware kit.

- 1 Un-pack and check for damage.
- 2 Remove cover plate of luminaire by removing the 2 screws. Save screws, as they will be used to finish assembly.
- 3 Loosen 2 captive screws that hold driver bracket in place. (Driver will swing out of the way).
- 4 Attach mounting bracket to junction box using the included hardware.
- 5 Position luminaire over threaded rod.
- 6 When positioned, secure with mounting nut - ensuring luminaire is flush to surface.
- 7 Connect line to black, neutral to white and ground to green with supplied wire nuts.
- 8 Swing driver back into position. Be careful not to pinch wires.
- 9 Re-secure driver to mounting plate with screws.
- 10 Re-install cover plate with 2 screws.

