

# Installation Instructions

SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

Turn Switch 2 ON for 3000K



Turn Switch 1 ON for 4000K



Turn Switch 1 and 2 ON for 3500K



Model#: 30012/30014/30018

Lamp Replacement: All wattage of compact fluorescent lamps

## WARNING

- ✘ Installation must be performed by a qualified licensed electrician
- ✘ Before installation, turn off the main power at the circuit breaker

## CAUTION:

- ✘ Use safety precautions. Always handle lamp by its base
- ✘ To prevent electric shock, do not insert any objects through openings or attempt to open the adapter

## NOTE:

- ✘ Take the fixture and the screw pack from the box, make sure that no parts are missing by referencing the illustrations on the installation diagram

## FIXTURE INSTALLATION:

- 1) Remove the screws (7) and take apart the acrylic lens (5) and the lens ring (6).
- 2) Mount 2 mounting screws (1) to the conjunction box on the ceiling. Pull the existing electrical wires out of the box.
- 3) Connect the supply leads from the electrical outlet box to the fixture wire leads using the wire nuts (2) provided in your screw pack as per the diagram. Make sure the "black lead" from the fixture goes to the "black supply lead", and the "white lead" the fixture goes to the "white supply lead". Thread wires to green ground screw.
- 4) Position the small metal base (3) over the conjunction box. Secure the fixture base (3) to the conjunction box with the canopy screws (1) protruding from the conjunction box pass through the elongated holes in the metal base. The metal base should be tighten up against the ceiling surface.
- 5) Compact fluorescent lamp (4) into the socket. Hold the lamp by its base.
- 6) Place the acrylic lens (5) over the fixture base. Place the lens ring (6) over the lens. Secure the lens with the screws (7).
- 7) Restore power to the electrical outlet box to make sure your fixture is working properly.

